JETMASTER[®] ROAD MAINTENANCE HIRE UNIT



Ausroad™ have a fleet of Road Maintenance units currently available for hire. We can deliver the units to any part of Australia and also supply operator.

The AUSROAD[™] Jetmaster[®] Road Maintenance Hire Unit is designed to deliver road maintenance tasks:

- » Self-loading of emulsion from drum capability
- » Heating options available
- » All Jetmasters automatic transmission
- » Great option for try before you buy
- » Increase your existing repair capacity with a hire unit for a period after rain event
- » Operator support throughout hire General maintenance repairs

FULL TRAINING AND BACK UP SUPPORT PROVIDED.

REGISTER YOUR INTEREST NOW

Contact Darryl Hunter - National Hire Manager - Road Maintenance M: 0473 473 313 or Email: support@ausroad.com.au

3A/147 Boniface Street Archerfield BC, QLD, 4108 Australia PO Box 1200 Archerfield BC. QLD, 4108 Australia ausroad.com.au +61 (7) 3216 7058

AUSROAD JETMASTER[®] ROAD MAINTENANCE



The spray bar and aggregate spreader can operate at full width (2.4 metres) or be used in any combination of eight 300mm wide gates, all controlled from the cab.

Blow patching via remote controlled front boom.

This process is extremely effective for heavy patching, shoulder seals, strip patching etc. Spray and cover rates are all controllable from the cab via the control system.

When the full width paver bar is in use, aggregate is sprayed with emulsion as it drops to the road before being levelled off with the paver bar. This is an effective and permanent solution whenever a surface correction is required. Uses include shoulder repairs, wheel rutting etc.

3A/147 Boniface Street Archerfield BC, QLD, 4108 Australia

PO Box 1200 Archerfield BC. QLD, 4108 Australia

ausroad.com.au +61 (7) 3216 7058 Contact Darryl Hunter - National Hire Manager - Road Maintenance M: 0473 473 313 or Email: support@ausroad.com.au